尺寸:140x100mm
材质:128G铜板纸，单色印刷，折叠页

IK105Pro

用户手册

FEKER

产品参数

产品品牌：FEKER
产品名称：IK105Pro
产品结构：有声Gasket结构
产品尺寸：429.3x143.8x44mm
产品重量：≈1050g
按键数量：104key
矩　阵：全键无冲
连接方式：有线-USB/蓝牙/2.4G
接　口：键线分离式type-c接口
电池容量:8000mAh
背　光：RGB（18模灯效）
键　帽：JSA热升华键帽
兼容性：Windows7/8/10/11/Mac/Linux/Android/ios

开关指示说明

MAC模式:开关按到MAC模式
WIN模式:开关按到win模式
上弹:2.4G模式
中弹:USB模式,出厂默认
下弹:蓝牙模式
CAPS指示灯:CAPS键盘光指示
Win指示灯:WIN键盘光指示
充电指示灯:充电时为键区红灯亮，充满熄灭,低电时红灯快闪

灯光效果说明

1、上电后，灯光亮白光围绕键盘跑动，跑完熄灭，跑完所有按键后，恢复被电前灯光状态。
2、灯光模式的选择是按照单击事件来上到下，最后切换模式后有0FF。
3、灯光效果
常用：| 渐变流水 | 光之单列 | 呼吸 | 彩云追飞 | 梅花跳跳 | 沙起流淌 | 随雪无痕 | 奔逸绝尘 | 百花争艳 | 梅流满动 | 流星赶月 | 大鹏展翅 | 川流不息 | 薄荷岭铃 | 左右逢源 | 众志成城 | 速度激情

休眠机制说明

1、深度休眠：键盘无按键操作20分钟后深度休机。蓝牙断开并且休眠，按任意按键唤醒键盘每光并回连蓝牙；
2、有电休眠：键盘无按键操作20分钟后有光关闭，按任意按键唤醒键盘每光并回连蓝牙；

滚轮功能说明

默认：静音/左V-/右V+

左下按：静音　　左转：音量-　　右转：音量+

模式连接说明

1、蓝牙模式连接
蓝牙名称：FEKER IK105Pro-1、FEKER IK105Pro-2、FEKER IK105Pro-3
①、FN+1：短按切换蓝牙1,长按蓝牙1配对；
②、FN+2:短 短按切换蓝牙2，长按蓝牙2配对；
③、FN+3F：短按切换蓝牙3，长按蓝牙3配对；
操作：键盘开机后，按下FN+1/2/3/3秒进入蓝牙模式，长按FN+1/2/3/3秒在键15、键盘进入对码状态，1/2/3/3指示灯白光快闪，连上后指示灯常亮25，找不到配对设备30s后，退出对码模式灯熄灭，键盘进入睡眠。

2、2.4G模式连接
短按切换2.4G，长按2.4G配对
操作：键盘开机后，按下FN+4/5进入2.4G模式，再按下FN+4/5超合键15进入配对模式后，插入接收器，4/指示灯白光快闪，配对成功后退出对码，模式灯常亮25，找不到配对设备30s后，退出对码模式灯熄灭，键盘进入睡眠。

按键复合功能键说明

组合按键	WIN功能	MAC功能（单按触发）	描述
FN+F1	此电脑	屏幕亮度减	按下组合键FN+空格，每次按下，数字键180键有灯显示电量点位，例如：1亮，表示10%电量；2和2 亮，表示20%电量，以此类推。（30%以下红色，50%以下黄色，50%以上绿色）。
FN+F2	主页	屏幕亮度加	
FN+F3	计算器	多任务控制器	
FN+F4	媒体库	程序列表	
FN+F5	上一曲	无	拨动开关选择MAC / WIN
FN+F6	下一曲	无	
FN+F7	播放暂停	上一曲	
FN+F8	暂停	播放暂停	
FN+F9	静音	下一曲	
FN+F10	音量-	静音	
FN+F11	音量+	音量减	
FN+F12	邮箱	音量加	
FN+BAKSPACE	长按15 复位	长按15 复位	键盘背光闪三次后光表示
FN+\;	键盘背灯按切换	键盘背灯按切换	闪烁：七彩、红、橙、黄、绿、青、蓝、紫、白
FN+Enter	键盘背灯按切换	键盘背光灯按切换	18种灯效默认键盘语言

按键复合功能键说明

组合按键	WIN功能	MAC功能（单按触发）	描述
FN+空格	查询电量（无线模式下电池供电有用）	查询电量（无线模式下电池供电有用）	按下组合键FN+空格，每次按下，数字键180键有灯显示电量点位，例如：1亮，表示10%电量；2和2 亮，表示20%电量，以此类推。（30%以下红色，50%以下黄色，50%以上绿色）。
FN+Home	END	END	~~~
FN+DEL	INS	INS	~~~
FN+L	键盘背光开关	键盘背光开关	~~~
FN+WIN+L	锁WIN	无	WIN亮蓝灯
FN+↑	灯光速度增	~~~	按照每切换上下加左灯闪烁3次指示。
FN+↓	灯光速度加快	~~~	按照每切换上下加左灯闪烁3次指示。
FN+ ↑	灯光亮度+	~~~	按照每切换上下加左灯闪烁3次指示。
FN+ ↓	灯光亮度-	~~~	按照每切换上下加左灯闪烁3次指示。
FN+→	灯效速度加快	灯效速度加快	按照每切换上下加左灯闪烁3次指示。
FN+ ←	灯效速度减慢	灯效速度减慢	按照每切换上下加左灯闪烁3次指示。

FEKER

Product parameters

Product brand: FEKER
Product Name: IK105Pro
Product structure: Leaf spring Gasket structure
Product size: 429.3x143.8x44mm
Product weight: ≈ 1050g
Number of keys: 104keys
Matric: Full key without impact
Connection method: Wired USB/Bluetooth/2.4G
Interface: Keywire separated type: interface
Battery capacity: 8000mAh
Backlight: RGB (18 sets of light effects)
Key cap: JSA thermal sublimation key cap
Compatibility: Windows 7/8/10/11/Mac/Linux/Android/iOS

Switch indication instructions

MAC mode: Switch to MAC mode
WIN mode: Switch to Win mode
Push up: 2.4G mode
Middle: USB mode, factory default
Push down: Bluetooth mode
CAPS indicator light: CAPS key blue light indication
Lock win indicator light: WIN key blue light indication
Charging indicator light: When charging, the FN button's red light is on and off when fully charged, and the red light flashes quickly when the battery is low



Lighting effect description

1. After powering on, the light turns on and the white light runs around the keyboard, and the tail turns off. After running all the buttons, the light state before powering off is restored.
2. The lighting order of the light mode is from top to bottom in the table, and after switching the mode, there is OFF.
3. 18 lighting effects

Explanation of Sleep Mechanism

1. Deep sleep: After 10 minutes of keyless operation on the keyboard, it will be in deep standby mode, with Bluetooth disconnected and dormant. Press any button to wake up the keyboard backlight and reconnect to Bluetooth;
2. Power-saving sleep: After 2 minutes of keyless operation on the keyboard, the backlight turns off. Press any button to wake up the keyboard backlight and connect back to Bluetooth;

Roller Function Description

Default: Mute/Left V -/Right V+

Press down: Mute　　Left turn: Volume-　　Right turn: Volume+

Mode Connection Description

1. Bluetooth Profile Connection
Bluetooth name: FEKER IK105Pro-1, FEKER IK105Pro-2, FEKER IK105Pro-3
①**FN+1:** Short press to switch to Bluetooth 1, long press to pair Bluetooth 1;
②**FN+2:**: Short press to switch to Bluetooth 2, long press to pair Bluetooth 2;
③**FN+3F:** Short press to switch to Bluetooth 3, long press to pair with Bluetooth 3;
Operation: After the keyboard is turned on, press and hold FN+1/2/@/3# to enter Bluetooth mode. Long press and hold the FN+1/2/@/3# combination key for 3S, and the keyboard will enter the code-checking state. The 1/2/@/3# indicator light will flash quickly and white, and the indicator light will remain on when connectedAfter being unable to find the paired device for 30s, the exit code-matching mode light turns off and the keyboard enters sleep.

2. 2.4G mode connection
Short press to switch to 2.4G, long press to pair with 2.4G
Operation: After the keyboard is turned on, press FN+4/5 to enter 2.4G mode, and then press the FN+4/5 combination key for 3S to enter pairing mode. After inserting the receiver, the 4/5 indicator light will flash quickly and white. Once pairing is successful, exit pairing.The mode light remains on for 2 seconds, and after 30 seconds when the paired device cannot be found, the exit code matching mode light turns off, and the keyboard enters sleep.

Key composite function key description

Combination button	WIN function	MAC function (single press trigger)	Describe
FN+Enter	Keyboard backlight effect switching	Keyboard backlight effect switching	Flip the switch to select MAC/WIN
FN+Space	Check battery level (wireless mode The power supply from the lower battery is effective	Check battery level (battery power is valid in wireless mode)	10.default light effects follow the current Press the combination key Fn+space, the backlight will turn off, and the number keys 1 to 0 will light up the light displays the proportion of battery power, for example: 1 is on, indicating 10% battery power, 1 and 2 on, indicates 20% battery capacity. And so on. (Below 30% in red, Below 50% yellow, above 50% green).
FN+Home	END	END	~~~
FN+DEL	INS	INS	~~~
FN+L	Keyboard backlight switch	Keyboard backlight switch	~~~
FN+WIN+L	Lock WIN	Nothing	WIN bright blue light
FN+↑	Light speed slows down	~~~	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+←	Accelerated light speed	~~~	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+→	Slow down light effect speed	Slow down light effect speed	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+↓	Keyboard backlight effect switching	Keyboard backlight effect switching	Keyboard backlight flashing three times with white light (Order: Colorful, Red, Orange, Yellow, Green, Green, Blue, Purple, White)

Combination button	WIN function	MAC function (single press trigger)	Describe
FN+ ↑	Light brightness+	~~~	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+ ↓	Light brightness-	~~~	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+ ←	Accelerated light effect speed	Accelerated light effect speed	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.
FN+ →	Slow down light effect speed	Slow down light effect speed	When in the extreme gear position, the up, down, left, and right lights flash three times to indicate.

产品质保

感谢您对FEKER产品的信任和支持，为了让您放心使用产品，更好的保证您的权益。
我司将严格遵守并执行相关规定，实行售后。
1、整机有效期：自购买之日起质量保证12个月，终生维护，配件不在保修范围内；
2、服务内容：按售型计算机商品维修更换是责任规定进行服务；
3、不属于保修范围：
a.已超出有效期及未免费维修期的；
b.未按照正确说明使用、维护、保管导致故障或损坏的；
c.由于不可抗力（如自然灾害等）原因造成的产品之外；
d.人为因素导致产品不良（如操作失误、碰撞、进水、输入不合适电压等）；
e.一切人为损坏、自行拆机、拆封过、使用不当等，不在保修范围。

质保卡

产品型号：_____
购买日期：_____
客户姓名：_____
联系电话：_____
联系地址：_____

品牌商:深圳市翰德嘉电子科技有限公司
地　址:深圳市宝安区沙井街道沙松路135号摩德国际C栋502
生产商:东莞市吉点动漫科技有限公司
地　址:广东省东莞市虎门镇镇马镇1号中电能量科技园7栋B5
执行标准：GB/T 14081-2010

合格证
FEKER
检验员
date

更多产品信息请关注
FEKER官网：
https://www.fekergaming.com